



## *Addendum: 460157001M Model 94x, 97x Proximity Reader Installation Guide*

### **Model 94x/97x Readers with part numbers ending in W02**

The following differences exist between Standard 94x/97x readers and -W02 readers.

- **Output Format**  
The 4001 Wiegand Output format has been replaced with the 4002 Wiegand Output format. Switch settings, referenced in the manual, used to select 4001, now select 4002.
- **Weigand 4002 output mode**  
Readers ship pre-configured to operate in Weigand 4002 output mode.
- **F/2F Operation**  
The -W02 readers, like the standard 94x/97x readers, are fully capable of operating in a variety of F/2F operational modes; simply follow the configuration instructions described in the manual.

---

Copyright © 9/29/04, GE Security, Inc. All rights reserved.  
This document may not be copied in whole or in part, or otherwise reproduced  
except as specifically permitted under US copyright law, without the prior written  
consent from GE.