

NOTIFIER AM2020/AFP1010 AND AFP200
CONVERSION OF 7 DIGIT HEX ERROR CODE TO 5 DIGIT PASSWORD, LEVELS
LEVELS 1 AND 2.

- 1 -- OBTAIN THE 7 DIGIT HEX CODE BY TRYING TO LOG ON TO PANEL. IF THE WRONG PASSWORD IS ENTERED, THE HEX CODE WILL BE DISPLAYED. EXAMPLE: 01019B5
- 2 -- USE THE FIRST THREE DIGITS OF THE HEX CODE, FROM THE EXAMPLE: 010, AND COMPARE THEM TO CONVERSION CHART #1. THIS WILL GIVE YOU THE FIRST TWO DIGITS OF THE PASSCODE. EXAMPLE: 010 = 02
- 3 -- USE THE NEXT TWO DIGITS OF THE HEX CODE, FROM THE EXAMPLE: 19, AND COMPARE THEM TO CONVERSION CHART #2. THE CLOSEST IN VALUE WITHOUT GOING OVER IS YOUR NEXT DIGIT. EXAMPLE: 19 IS CLOSEST TO 18 IN CHART, 20 IS GOING OVER. 18 = 3, 3 IS YOUR THIRD DIGIT.
- 4 -- USE THE HEX CODE IN STEP 3 AND ADD TWO ZEROS TO THE RIGHT SIDE. EXAMPLE: 18 + 00 = 1800
- 5 -- USE THE LAST FOUR DIGITS OF HEX CODE AND SUBTRACT THE NUMBER OBTAINED IN STEP 4. EXAMPLE: 19B5 - 1800 = 1B5
NOTE: REMEMBER TO SUBTRACT IN HEX!!
- 6 -- USE THE HEX NUMBER OBTAINED IN STEP 5 AND COMPARE IT TO CONVERSION CHART #1. THIS WILL GIVE YOU THE LAST TWO DIGITS OF PASSWORD. EXAMPLE: 1B5 = 35
- 7 -- PUTTING THE DECIMAL NUMBERS TOGETHER, YOUR PASSWORD IS 02335.

00	000	20	11D	40	23A	60	327	80	474
01	008	21	115	41	232	61	32F	81	47C
02	010	22	10D	42	22A	62	337	82	464
03	018	23	105	43	222	63	33F	83	46C
04	020	24	13D	44	21A	64	307	84	454
05	028	25	135	45	212	65	30F	85	45C
06	030	26	12D	46	20A	66	317	86	444
07	038	27	125	47	202	67	31F	87	44C
08	040	28	15D	48	27A	68	367	88	434
09	048	29	155	49	272	69	36F	89	43C
10	080	30	19D	50	2BA	70	3A7	90	4F4
11	088	31	195	51	2B2	71	3AF	91	4FC
12	090	32	18D	52	2AA	72	3B7	92	4E4
13	098	33	185	53	2A2	73	3BF	93	4EC
14	0A0	34	1BD	54	29A	74	387	94	4D4
15	0A8	35	1B5	55	292	75	38F	95	4DC
16	0B0	36	1AD	56	28A	76	397	96	4C4
17	0B8	37	1A5	57	282	77	39F	97	4CC
18	0C0	38	1DD	58	2FA	78	3E7	98	4B4
19	0C8	39	1D5	59	2F2	79	3EF	99	4BC

CHART 1

0	00
1	08
2	10
3	18
4	20
5	28
6	30
7	38
8	40
9	48

CHART 2

Notifier Fallback Codes

00	000	51	2B2	000	0000	051	02B2
01	008	52	2AA	001	0008	052	02AA
02	010	53	2A2	002	0010	053	02A2
03	018	54	29A	003	0018	054	029A
04	020	55	292	004	0020	055	0292
05	028	56	28A	005	0028	056	028A
06	030	57	282	006	0030	057	0282
07	038	58	2FA	007	0038	058	02FA
08	040	59	2F2	008	0040	059	02F2
09	048	60	327	009	0048	060	0327
10	080	61	32F	010	0080	061	032F
11	088	62	337	011	0088	062	0337
12	090	63	33F	012	0090	063	033F
13	098	64	307	013	0098	064	0307
14	0A0	65	30F	014	00A0	065	030F
15	0A8	66	317	015	00A8	066	0317
16	0B0	67	31F	016	00B0	067	031F
17	0B8	68	367	017	00B8	068	0367
18	0C0	69	36F	018	00C0	069	036F
19	0C8	70	3A7	019	00C8	070	03A7
20	11D	71	3AF	020	011D	071	03AF
21	11S	72	3B7	021	011S	072	03B7
22	10D	73	3BF	022	010D	073	03BF
23	10S	74	387	023	010S	074	0387
24	13D	75	38F	024	013D	075	038F
25	13S	76	397	025	013S	076	0397
26	12D	77	39F	026	012D	077	039F
27	12S	78	3E7	027	012S	078	03E7
28	15D	79	3EF	028	015D	079	03EF
29	15S	80	474	029	015S	080	0474
30	19D	81	47C	030	019D	081	047C
31	19S	82	464	031	019S	082	0464
32	18D	83	46C	032	018D	083	046C
33	18S	84	45L	033	018S	084	045L
34	1BD	85	45C	034	01BD	085	045C
35	1BS	86	444	035	01BS	086	0444
36	1AD	87	44C	036	01AD	087	044C
37	1A5	88	43J	037	01A5	088	043J
38	1DD	89	43C	038	01DD	089	043C
39	1DS	90	4F4	039	01DS	090	04F4
40	23A	91	4FC	040	023A	091	04FC
41	232	92	4E4	041	0232	092	04E4
42	22A	93	4EC	042	022A	093	04EC
43	222	94	4D4	043	0222	094	04D4
44	21A	95	4DC	044	021A	095	04DC
45	212	96	4C4	045	0212	096	04C4
46	20A	97	4CC	046	020A	097	04CC
47	202	98	4B4	047	0202	098	04B4
48	27A	99	4BC	048	027A	099	04BC
49	272			049	0272	100	0800
50	2BA			050	02BA		0A0A